Vantage *VUE*® INSTALLATION DIAGRAM

WeatherLinkIP (#6555) lets you easily see your weather data live on the Internet. Simply plug the data logger into the back of your Vantage Vue or Envoy console, connect the cable to your cable/DSL router, and within minutes you can see your weather data live on the Internet.

PCs running WeatherLink software on LAN can communicate directly with Vantage Vue console and display live data as it arrives at the console.

LAN

Router

Broadband Modem

WeatherLink.com
Current data every 1 minute
Archive upload every 1 hour

View live weather at weatherlink.com with your browser.

A PC running WeatherLink software can download archived data from weatherlink.com